

PART NUMBER	DESCRIPTION	UNITS PER ASSY	USABLE ON CODE
USM5W	SWITCHES INSTALLATION-LANDING GEAR		
1550005-2	SWITCH-GEAR WARNING		
1550005-2	ATTACHING PARTS		
SEE FIG 82A	UMX		
AN515-2R10	BRACKET	NP	
AN960-2	FRONT & REAR ENGINE INSTL	2	
1450020-1	BRACKET		A
1560218-1	FRONT ENGINE ONLY	2	B
	REAR ENGINE ONLY	1	
	SCREW	1	
	WASHER	1	
	INSULATOR	2	
	PLATE ASSEMBLY	2	
	*---	1	
1450009-1	CAM	1	
S2088-1	SWITCH-MAIN GEAR DOWNLOCK		
JE1	ACTUATOR-SWITCH	1	MCS
AN93683	WASHER	2	
MS21042-02	NUT	2	
YZ2RQIT	SWITCH-MAIN GEAR UPLOCK	4	MCS
	ATTACHING PARTS	4	
	SCREW	2	
	WASHER	2	
	NUT	2	
	*---		
1541044-1	SUPPORT-LH	1	
1541044-2	SUPPORT-RH	1	
	ATTACHING PARTS		
	SCREW	2	
	NUT	2	
	*---		
AN515-6R7	SWITCH-NOSE GEAR UP & DOWNLOCK	2	
MS21045L06	SWITCH-SQUAT	1	
	BRACKET ASSEMBLY-SQUAT SWITCH	1	

A---337 SERIAL 33701463 THRU 33701671
 F337 SERIAL F33700056 THRU F33700076
 B---337 SERIAL 33701672 & ON
 F337 SERIAL F33700077 & ON

